

## COMPACT MAX

Portable reader

### Highlights

- Best-in-class reading performances
- Extremely easy to use
- Slim and elegant design
- Pocket size, lightweight
- Long Lasting, rechargeable, lithium battery
- Bright color display
- Store up to 4'000 microchip codes
- Easily transfer codes to a PC



### Description

COMPACT MAX: the best of Datamars reading technology packed in an extremely reduced form factor!

Thanks to its peripheral antenna, COMPACT MAX features top of range reading distances in only 160x80x20 mm and 170g. The scanner can easily fit in any pocket and is able to read FDX-B (ISO) and FDX-A/Fecava. Its basic protection against water also makes it the ideal scanner to use in any condition. From puppies and kittens to seniors, COMPACT MAX delivers the identification you need.

The scanner can be connected to a PC through its USB port and transfer the microchip codes during or after the reading session. The connection is totally plug and play, no set-up is needed. COMPACT MAX has great ergonomics and a very intuitive icon-based, graphic interface which makes it the easiest reader to use on the market.

### Technical Data

Dimensions	L160xW80xT20 mm
Weight	170g
Operating temperature	-5degC to +55degC, 95% RH, non condensing
Charging temperature	+5degC to +45degC, 95% RH, non condensing
Storage temperature	-20degC to +65degC, 95% RH, non condensing
Battery	Li-ion (1250 mAh)
Com interface	USB (Mass storage, VCP and Keyboard wedge)
Typical reading distance	FDX-B (134.2 kHz) 12 cm FDX-A/Fecava (125 kHz) 7 cm
Housing	White ABS, water-resistant (with USB cap inserted)
Approved by	CE/FCC National approval in Canada, Australia and New Zealand
Standards	ISO 11784/5 (FDX-B) Non-synchronizing transceiver

Subject to change without notice

### DATAMARS

Corporate Headquarters:  
Via ai Prati  
6930 Bedano-Lugano  
Switzerland  
Phone: +41 91 935 73 80  
Fax: +41 91 945 03 30  
animal-id@datamars.com  
www.datamars.com